

Bench Scale Columns

Part Number/Price

Part #	Description	Price
112044	12 in column for IQ plus® 210, CW-90, CW-90X, 480/482 Legend Series, 380 Synergy Series, 680 Synergy Series	Consult
112045	18 in column for IQ plus® 210, CW-90, CW-90X, 480/482 Legend Series, 380 Synergy Series, 680 Synergy Series	Consult
196363	12 in column for 882IS/882IS Plus with battery	Consult
196364	18 in column for 882IS/882IS Plus with battery	Consult
197482	12 in column for 882IS/882IS Plus with power supply (Note: Power supply does not mount to column)	Consult
197484	18 in column for 882IS/882IS Plus with power supply (Note: Power supply does not mount to column)	Consult
64576	Attachment bracket for IQ plus® 210, CW-90, CW-90X, 480/482 Legend Series, 380 Synergy Series, 680 Synergy Series	Consult
216970	12 in column for 381 Synergy Indicator	Consult
216971	18 in column for 381 Synergy Indicator	Consult

Available for the BenchMark SL, BenchMark SL/HE, BenchMark Mild Steel, BenchMark Stainless Steel, BenchMark HE, BenchMark HE-X, CW-80B, CW-90B and CW90-XB



CW-90B with 480 indicator and 12in column



Base with 882IS/882IS Plus indicator with battery and 12in column



Attachment bracket with IQ Plus 2100



Base with 381 Synergy indicator and 12in column